



NOTES:

1. TRENCH SIDE SLOPES SHALL BE IN ACCORDANCE WITH OSHA REQUIREMENTS. BEGIN SIDE SLOPES, IF USED, APPROXIMATELY 18" ABOVE TOP OF PIPE (TYPICAL ALL BACKFILL TYPES).
2. ADD MAGNETIC WARNING SAFETY TAPE ABOVE ALL PRESSURE SEWER LINES. TAPE SHALL BE PLACED DIRECTLY ABOVE PIPE CENTERLINE, 12-18 INCHES BELOW FINISHED GRADE

RIGHT-OF-WAY RESTORATION

DETAIL

NO SCALE

