



NOTES:

1. CUT HOLE IN EXISTING MANHOLE WITH CORING MACHINE.
2. INSTALL FLEXIBLE NEOPRENE BOOT.
3. FILL ANNULAR SPACE WITH NON-SHRINK GROUT.

NEW SEWER TO EXISTING MANHOLE CONNECTION

DETAIL

NO SCALE

