



CONDUIT AND WIRE SIZING TO DEPEND ON POWER REQUIREMENTS OF THE CONTROL PANEL AND THE DISTANCE BETWEEN THE PANEL AND SERVICE ENTRANCE. NEC AND BOCA CODES MUST BE FOLLOWED AND TAKE PRECEDENCE.

**POST-MOUNTED CONTROL PANEL
(EXTERNAL INSTALLATION)**

DETAIL

NO SCALE